



Scan Sport, Inc.

May Street • P.O. Box 700 • Enfield, New Hampshire 03748-0700 USA

Tel: (603) 632-9500

Fax: (603) 632-5611

web: www.pakboats.com

e-mail: info@pakboats.com

Puffin Foot Brace Installation instructions

1. Inflate the foot brace with the pump or by mouth. Close the valve cap.
Note: There is a large cap for deflation. The large cap has a smaller one at the center for inflation.

2. With little pressure in the side air sponsons, remove the "C" cross rib in the bow. Hook the elastic cord on the foot rest over the latch clip and reinstall rib "C". Your foot brace should now match the left hand side of the picture.



3. Remove the "B2" cross rib and install the strap around the "A" cross rib so that the latch clip for rib "B2" is inside the "V" formed by the straps. Reinstall cross rib "B2". Your foot brace should now match the installation shown in the picture.

4. Inflate the side air sponsons to full pressure and install the deck if your Puffin has one.

You can adjust the position of your foot rest while sitting on the seat by changing the length of the strap and pressing against the foot brace with your feet. The buckle is just in front of the seat within easy reach.

PAKBOATS

QUALITY FOLDING BOATS